

RefTalk Xtreme

Quick Users Guide



ID and Group

- ID range are 1-32
- ID as (1) is always the Master. All others must follow in sequence
- Group range are 1-16
- One radio must be set as the Master or (1). All others must follow in sequence

Change ID

1. Press the (M) button for 3 seconds while power is on
2. ID and number will begin blinking
3. Use the Up/Down buttons to change the ID and immediately press the (OK) button.
4. The GR and number will begin blinking
5. Use the Up/Down buttons to change the Group and immediately press the (OK) button.
6. The radio will turn off to complete the new settings (ID & Group)
7. Press the Power button to turn on the radio with the new settings

Mute the microphone. Press the (OK) button

- Talk mode – No Icon
- Mute mode – Icon is displayed on the LCD screen
- When turning on all radios, the Master microphone default is On. **All slaves default as Muted when powered on.**

Lock all buttons

1. Press and hold the (M) & (OK) buttons
 - a. ID/GR/Number will blink 5 times
 - b. Buttons locked
2. Press and hold the (M) & (OK) buttons to unlock
 - a. ID/GR/Number will blink 5 times
 - b. Buttons unlocked